

DAVENTE

Top Mount

INSTALLATION INSTRUCTIONS

**BEFORE following these 4 easy steps,
please note:**

Depending which size you purchased, these vents are designed for either a 3"x10" or 4"x10" duct size and for 3/8" - 1/2" thick material. If your material is thinner than that, you will need to add a substrate underneath to build up the thickness.

STEP 1

Cut a piece of your flooring material to the appropriate size: 223mm x 42mm for a **3x10**, or 223mm x 67mm for a **4x10**, and sand to fit.

[If your material is thinner than 3/8", cut a substrate to the same size or slightly smaller.]

STEP 2

Bond cut to size material to the tray using silicone, or a similar adhesive.

STEP 3

Open the diffuser tabs to your required air flow.

STEP 4

Place the tray into your 3x10 or 4x10 duct opening and enjoy your beautiful new tile vent.

If you require further assistance with the installation of this product, please feel free to contact us at info@made2match.ca or call **1-877-636-1113**.

This product is
by
Made2Match Premièr Vents
and manufactured
by
DGM Enterprises
1173 North Service Road West, Unit 8
Oakville ON, L6M-2V9

For other Made2Match Products, please visit
www.Made2MatchVents.com

All of our products are proudly
MADE IN CANADA.

